
## **SRT MINI Instruction Manual**

#### 1. APPLICATIONS

- Smart control product range, intelligent code, safe, reliable and cannot be copied.
- Insertable card for control panels in oRder to faciltate remote control access.
- Activation by the memorised fuction.

### 2. BRIDGE SELECTOR




PANEL DE CONTROL /RECEPTOR CONECTOR


#### **RADIO PROGRAMMING MODE:**






#### 3. TRANSMITTER MANUAL PROGRAMMATION





#### 3.1 TRANSMITTER RADIO PROGRAMMING



SRT MINI - 1-2

#### **3.2 MEMORY RESET**















**PULSAR** 

1 X BIP

LED ON

KEEP IT PRESSED

# BIPS

RELEASE

SE WAIT









LED OFF

2 X BIPS

SAVE & EXIT

#### TECHNICAL SPECIFICATIONS Power Control Pannel 12V Power consumption 16mA Output type Open collector 100mA Available codes 2.097.152.281 Millions Encryption technology Hopping code Key Encryption 64 bits 2 CRC bits Detection of errors during transmission 255 / 1000 different codes Number of codes Frecuency 433.92 or 868.35MHz Certificates ETS300-220/ETS300-683 Spurious emissions < -57dBm Sensitivity < -104dBm 60m

0 to 70°

17cm / 8,5cm

# **WARNING!!**

- Equipment installation and start-up, can only be executed by qualified personal.

CE DECLARATION OF CONFORMITY For more information visit the website www.aerf.eu





 $\epsilon$ 

Temperature Antenna